

Vacuum and Atmosphere Services pride ourselves on being innovative and proactive. Our new LEAP service is a commitment to our customers. LEAP is an industry first and is designed to give our customers complete confidence in our product, quality and performance.

Each level of service is tailored to our customer's requirements.

**Scope of supply:**

## Essential

1. Check and top up oil levels
2. Measure pump pressures / currents
3. Check fan / convection motor currents
4. Check all safety functions
5. Check all furnace performances
6. Inspect hot zone
7. Leak check

## Advanced

1. Change pump oils
2. Change all butterfly valve inserts
3. Change all PLI seals
4. Change all water pressure o/p valves
5. Inspect hot zone
6. Burn out furnace
7. Measure leak up rate
8. Thermal image vessel at high temp
9. Thermal image control panel connections
10. Measure pump pressures / currents
11. Check fan / convection motor currents
12. Check all safety functions
13. Check all furnace performances
14. Leak check furnace

## Premier

1. Change pump oils
2. Change all butterfly valve inserts
3. Change all cylinder seals
4. Change all PLI seals
5. Change all water pressure o/p valves
6. Remove hot zone and clean vessel
7. Change all insulators and support hangers
8. Remove and clean diffusion pump
9. Burn out furnace
10. Measure leak up rate
11. Thermal image vessel at high temp
12. Thermal image control panel connections
13. Measure pump pressures / currents
14. Check fan / convection motor currents
15. Check all safety functions
16. Check all furnace performances
17. Leak check furnace
18. Supervise first production load

To discuss your requirements  
call us on

**0121 544 4385**

**E-Mail enquiries@vacat.co.uk**

